



# Operating Manual

**Model 233v3**  
**Pulsed DC**  
**Controller**



# Contents

Introduction	3
Unpacking and Inspection	4
How to use your controller	5
Control Adjustments	7
Alarm	8
LED Displays	8
Technical Specification	9
Cleaning Instructions	10
Fault Finding	11
Repairs and Warranty	13
CE Approval	13
Health and Safety	13

Products shown in this document may be covered by one or more patents, patents applied for and/or registered designs and/or trade marks. For further information please refer to our Head Office or visit [www.meech.com](http://www.meech.com).



# Introduction



The Meech Model 233v3 Pulsed DC Controller has been designed to power any of the Meech 200 series range of PDC products.

# Unpacking And Inspection

The Model 233v3 Power Supply was carefully packed at the factory in a container designed to protect it from accidental damage. Nevertheless, we recommend careful examination of the carton and contents for any damage. If damage is evident, do not destroy the carton or packing material and immediately notify the carrier of a possible damage claim. Shipping claims must be made by the consignee to the delivering carrier.

## Contents:

Included with the Model 233v3

1. Instruction Manual

2. DC power plug, 2.1mm ID



3. 15W Switchmode with 2m of LT cord



## Options

1. Mini DIN control cable, 2000mm



2. 3.5mm mono jack plug for remote on/off



# How To Use Your 233v3 Controller

1. Locate the 233v3 controller in a convenient position near to the ionising product to be powered from it.
2. Following the polarity indicators connect the grey HV plugs of the ionising product into the grey HV output sockets of the 233v3.



3. Connect the 24VDC input supply to the controller and switch ON. A Mains lead for the Meech switch mode power supply is provided. The mains supply to the switch mode must be electrically grounded.



If using anything other than the Meech 24V supply please note the zero volt (0V) must be electrically grounded (connected to earth).

The attached ioniser will now produce Pulsed DC ionisation from its emitter pins.

## For Best Results

1. Keep target area clear and free from obstructions to ion flow.
2. Keep work area clear of all static generative materials.
3. Only use approved static control grounding methods and material handling equipment.



# Control Adjustments

There are two adjustments that can be made on the 233v3 controller; BALANCE, and RATE .

The BALANCE of positive and negative ion output can be adjusted to increase polarity bias by simply turning the balance control towards either positive (right) or negative (left).

When set to maximum +VE or -VE the split is 20/80 - ie at maximum positive 80% of the ions are positive and 20% of the ions are negative (or vice versa)

The RATE POT allows the pulse frequency to be adjusted. The rate can also be set to SSDC mode; both the positive and negative outputs are on constantly. (See scale on product label). In pulse mode the frequency can be adjusted from 0.5 to 20 Hz. The lower the frequency (RATE) the greater the range (ie distance over which the ionisation will travel). A setting of 5 to 10Hz is recommended for most applications.



When set to SSDC mode the effective range of ionisation is up to 200 mm from the ionising bar.

The purpose of these adjustments is to give total versatility to the positioning of the ionising product attached to it.

Remember it is important to verify calibration after any adjustments and before using your ioniser around sensitive electronics.

# Alarm

The alarm feature detects faults in the operation of the ionising system, e.g. problems caused by lack of product cleanliness. When a fault has been detected the alarm LED will illuminate and the high voltage to the emitters will be automatically switched off. If a single occurrence of a fault occurs, the controller will switch off the HV for 1 second and then automatically reset. However, if the unit detects 5 faults in 5 seconds the HV will be permanently switched off. The fault must be removed (e.g. by cleaning of the ionising product) and the controller reset by switching the mains supply to it OFF and ON.

An 8 way DIN socket is provided to mirror the alarm function to a central control panel (see specification for connection detail).

## LED Displays

The 233v3 has four indicator lights

- |                                   |   |
|-----------------------------------|---|
| 1. Power light (Red)              | - Illuminated when 24VDC supply is provided to the unit.        |
| 2. Alarm light (Orange)           | - Illuminated when unit has detected a fault and has shut down. |
| 3. Positive balance light (red)   | - indicates positive voltage and pulse rate                     |
| 4. Negative balance light (green) | - indicates negative voltage and pulse rate                     |



# Technical Specification

## Model 233v3 Power supply

Input voltage	:	24V D.C (+/- 5% 0.25A max- source must have earth return)
Input connector	:	2.5mm jack - centre positive
Output voltage	:	Adjustable between 4kV D.C. and 8kV D.C.
Output current	:	120 Micro amps.
Output balance	:	Adjustable between a ratio of positive and negative of 20/80 to 80/20.
Output frequency	:	Adjustable between 0.5Hz and 20Hz or can be set to SSDC mode
Weight	:	0.3kg
Remote On / Off	:	3.5mm Jack
Alarm relay	:	8 pin DIN connector

Pin 1 Relay normally closed contact

Pin 2 Ground

Pin 3 +24V

Pin 4 Relay normally open contact

Pin 5 Not used

Pin 6 Relay common contact

Pin 7 Feedback signal

Pin 8 Not used

Note: RL1 is only rated for 24V dc 5 amp

Operating temp. :-10 Deg C to +65 Deg C

Short circuit

Back up protection: Controller must be supplied from a switched outlet incorporating a 1 amp fuse.

# Cleaning Instructions

Your Meech Pulsed DC Controller was designed to be virtually maintenance free.

1. Be sure the unit is switched off and disconnected from the mains supply.



2. The outside case may be wiped down with a soft damp cloth.



3. Let dry for a minute and turn back on.

# Fault Finding

Tests must be completed by a qualified electrical engineer.  
If in doubt contact Meech head office or your local distributor.

**CAUTION:** Whilst no danger to personnel exists, it is essential than any high voltage ionising equipment, makes no contact with water or water based fluids.

Should such an event occur, disconnect immediately and return equipment to the manufacturer for water damage assessment. High voltage electrical equipment should not make contact with water.

The Model 233v3 Power Supply and attached ionising products form part of a system. To verify where a fault may have occurred it is important to test each item of the system individually. Should more than one ionising appliance be connected to the power supply, these must be tested individually.

To check the Pulsed DC system, follow the procedure detailed below:

1. Switch off the electrical supply to the system.



2. Disconnect all ionising appliances from the controller.



3. Reconnect the supply and switch ON the unit.
4. Using a high voltage probe ( 1000:1 ) and meter measure the voltage on each of the output sockets. The reading should be at Max. power 8 kV



5. If the controller is found to be functional, test each of the attached products independently following the instructions detailed in the appropriate Operation and Maintenance manual.

If the 233v3 controller is found to be faulty please contact your local distributor or Meech Static Eliminators Ltd. ( Tel. +44(0)1993 706700).

# Repair and Warranty

The Meech Model 233v3 Pulsed DC Controller is warranted by Meech Static Eliminators Ltd to the original purchaser against defects in material and workmanship for one year after purchase. Should any malfunction occur, please return the Ioniser directly to us. All products returned to the factory MUST be accompanied by a return authorisation number and must be shipped prepaid. For prompt service, ship the unit to the factory with the return authorisation number shown clearly on the label. Be sure it is well packed in a sturdy carton with shock absorbing material.

Include a note stating the nature of the problem as specifically as possible, and also include instructions for returning the Ioniser to you. We will pay one-way return surface shipping costs on any repairs covered under the warranty.

Field repairs should not be undertaken during the warranty period. Repair attempts by unqualified personnel will invalidate the warranty.

## CE Approval

An EC Declaration of Conformity for this product exists in respect of the Low Voltage Directive: 72/23/EEC ("LVD") & Electromagnetic Compatibility Directive: 89/336/EEC ("EMCD")



## Health and Safety

Emission of Ozone: Considerably below international standard of 0.1ppm.

**Meech International**

2 Network Point  
Range Road, Witney  
OX29 0YN, UK

Tel: +44 (0)1993 706700  
Fax: +44 (0)1993 776977  
email: sales@meech.com

**Meech Static Eliminators  
(Shanghai) Co. Ltd**

7G, 7F, LP Tower  
#25 Xiangfeng Road  
201103 Shanghai  
China

Tel: +86 400 820 0102  
Fax: +86 21 6405 7736  
email: china@meech.com

**Meech Static Eliminators USA Inc**

1298 Centerview Circle  
Akron, OH 44321  
USA

Tel: +1 330 564 2000 / 1 800 232 4210  
Fax: +1 330 564 2005  
email: info@meech.com

**Meech Shavotech**

29/2, Kharadi  
Off Pune-Nagar Road  
On Old Kharadi Mundhwa Road  
Pune : 411014 , Maharashtra  
India

Tel: +91 (0)703 093 8211 / +91 (0)741 000 4817  
Fax: +91 (080) 28395963  
email: india@meech.com

**Meech Elektrostatik SA**

Kaiserbaracke 166  
B-4780 St.Vith  
Belgium

Tel.: +49 (0)6555 3733 399  
+32 (0)80 670 204  
Fax: +32 (0)80 862 821  
email: mesa@meech.com

**Meech International  
(Singapore) Pte. Ltd.**

7 Temasek Boulevard  
12 - 07 Suntec Tower One  
Singapore  
Singapore  
038987

Tel: +65 65918859  
email: singapore@meech.com

**Meech CE**

Gábor László utca 2  
Budapest 1041  
Hungary

Tel: +36 1 7977039  
+36 30 2803334  
email: ce@meech.com